
COVID BUSTER 2000



An integrated and embedded prototype
by Stefan Wick, Vladimir Brazhnik, Dennis Briner



Use Cases



Notifications

The app user will get notified when to ventilate a room to keep the covid infection rate at a minimum





Overview

A user can access the status for all registered rooms



Covid-19 App Monitor

A user is able to see how many people are using the covid-19 app. This will help to decide for an additional need of contact tracing



Why ventilation conditions matter?

- Every person exhales around 8 liters of air per minute.
- In addition to the CO₂, exhaled air contains aerosols, which, due to their small size, can stay in the air for a long time.
- The aerosols from an infected person can also contain virus particles. If healthy person inhales the necessary amount of contaminated aerosols, the disease can be transmitted.

How we can prevent the infection?

- Depending on the CO₂ concentration in a room, it is possible to determine what percentage of the air has already been exhaled by other people.
- A CO₂ concentration of approx. 1200 ppm shows, for example, that almost 2% of the air in the room has already had lung contact at least once.
- With good ventilation of the rooms the risk of infections can be reduced.

CO₂-concentration threshold values

< 1000 ppm

Recommended area:

Ventilate from approx. **800 ppm** in such a way that a value of **500 ppm** is **reached** and the value **above 1000 ppm** is never **exceeded**

1000 - 2000 ppm

Alarming area:

Immediate ventilation of the room with the aim of keeping the concentration **below 1000 ppm**


> 2000 ppm

Unacceptable area:


Leave the room and ventilate until a **value below 1000 ppm** has been reached again

Screenshots


Room List Screen




Current Room Screen




No Room Found Screen



History Screen




System architecture



Send CO2 value
and room ID



BLE advertisement
(non connectable)



Store co2 values
and get history



HTTPS request



Adafruit nRF52840

Measure CO2 value


Android smartphone

Shows room list, history
and actual co2 value and
measures active covid
apps

ThingSpeak


Stores CO2 value for
each room

State machine nRF52840




- BLE advertising interval is set to $160 \times 0.625\text{ms} = 100\text{ms}$
- Independent from state machine

Class Diagram



Code Quality: Tests

Tests on Android



on Arduino

Testing...
If you don't see any output for the first 10 secs, please reset board (press reset button)

```
test/test_main.cpp:86:test_basicTest [PASSED]
test/test_main.cpp:87:test_led [PASSED]
test/test_main.cpp:88:test_sensor [PASSED]
test/test_main.cpp:89:test_payload [PASSED]
test/test_main.cpp:90:test_alert [PASSED]
test/test_main.cpp:91:test_measurements [PASSED]
```


6 Tests 0 Failures 0 Ignored

===== [PASSED] Took 22.14 seconds =====

Test	Environment	Status	Duration
*	adafruit_feather_nrf52840_sense	PASSED	00:00:22.141
===== 1 succeeded in 00:00:22.141 =====			

Code Quality: Sonar

- Sonar ignores our tests
- 1 Codesmell cause of too many Dependencies in MainActivity



Project Evaluation

What went well

- Collaboration with three people
- Project Management with Kanban Board hosted on Trello
- No surprises using the CO₂ sensor


Project Evaluation

What went not as planned

- We chose not to pair with the peripheral, but to use the advertisement for data transmission
- We spend way more time to complete this project than we expected for a 3 ECTS module

Project Highlights

There was some overtime work involved 🧐



Outlook

- Before going to production:
 - Case for the controller and less parts
 - Better Room Management
- Attach Controller to Wi-Fi and make it configurable over BLE



Meet The App

Demo Video